

Quantum Data 980 Upgrade to GUI 1.0.60, Firmware 20.1C

This update to the 980 includes a new version of the PS-980 Manager (the graphical user interface for Windows) as well as a new version of the firmware/gateway load for the instrument itself. *All updates should be performed at the same time, as the PS-980 Manager GUI relies on some new features in the instrument firmware.* Here is the installation procedure:

1. Download the 980 Manager and Firmware from the Quantum Data Downloads page: <http://www.quantumdata.com/downloads/index.asp> to your PC.
2. First install the new Manager. If you have a previous version of the Manager installed, it will be replaced with the new version, 1.0.60. Start the installation by double-clicking on your downloaded **ps980-mgr-1.0.60.msi** file.
3. Proceed through the Setup Wizard as prompted. We recommend installation in the default folder.
4. After installation completes, run the new PS-980 Manager. It should be available in the Start Menu under All Programs → Quantum Data, and also from an icon on your Desktop.
5. Verify the version number in the title bar: Version 1.0.60
6. Connect the 980 instrument to your network and turn it on. After booting, you should see the instrument's IP address in its front-panel LCD.
7. Define the instrument in PS-980 Manager. In the Capture Control tab, click the + to the right of *Instrument Selection* at the top.
8. If the instrument is not automatically discovered, define the 980 by entering your choice of a name in the *PS-980 Name* field, and the instrument's IP address in the *IP Address* field. Click *Add*.
9. If at this point you see an error message, it is because the instrument itself still has old firmware which is not optimized for the new PS-980 Manager, so you should perform sub-step 'a' below. Otherwise proceed to step 10.
 - a. Under *Capture Control* → *Instrument Selection*, click on the pull-down in the entry box under *Select the instrument that will execute the capture*, and select the name of the instrument that you just defined. The IP address may be displayed incorrectly because of the old instrument firmware.
10. Click on the *PS-980 Navigator* tab. You should see the instrument name that you just defined. If it is not selected, right-click on it and select *Connect*. If the IP address is wrong, this is also because of the old firmware, so right-click and select *Disconnect*, then right-click and again select *Connect*.
11. Now under the *PS-980 Navigator* tab you should see the name of your 980 instrument followed by [connected]. Right-click on this name and select *Upgrade Firmware/Gateway*. Browse to the location of the downloaded **ps980_20_1_c.deb** file, select this file, and click *Open*.
12. You should see the *Progress Information* box that shows status of the upgrade process. Then you will see an information box telling you that the 980 will be powered down, and instructing you to then turn it back on. When you see from the front panel display that it has fully booted, click *OK* in this box.
13. Finally, right-click on the instrument in the PS-980 Navigator tab and select *Connect*. PS-980 Manager should connect to the instrument and update the version information for that instrument (you may have to click on the + to the left of the instrument to see this information.) Verify the following version information: (If any of these values are not populated, disconnect and reconnect.)
 - a. Firmware Version: 20.1 Build Number: 255 11/04/2009
 - b. Gateway Version: 12 Build: 10:27:2009: Rev: 500c
14. Now your 980 and Manager software are upgraded and ready for use.